

## POWER STATION™



Article number	3023997
Accessories	3 clipper tool inserts 2 trimmer tool inserts 1 shaver tool insert Power supply and cord Operating Instructions
AN	0043917010939
Unit	1 Stück

Charge **ANY COMBINATION** of three cordless 5V Wahl Professional clippers, trimmers and shavers.

**SIX INTERCHANGEABLE INSERTS** allow you to customize the Power Station to the tools you need recharged.

Charge a phone, mobile payment device or tablet directly from the charge station's **USB-C port**, without the clutter of an additional power cord.

## **Accessories**

